

TLRLB81-02M (V5) TOYOTA FORTUNER WAGON TOUGH BAR - TLR 18 & TLR18RM . (COMPATIBLE WITH YAKIMA MOULDED TRACK)

TLRAL18

TLRAL18

1800

END OF
ROOF TOP

REAR OF VEHICLE

REAR CTR - CTR WIDTH OF TRACK: 1035mm

FRONT CTR - CTR WIDTH OF TRACK: 1080mm

ROOF TOP PROFILE

MOULDED TRACK FITS INTO DITCH

FITTING INSTRUCTIONS

MOULDED TRACK MOUNT

TOYOTA FORTUNER WAGON (LB KIT81-02M) TOUGH BAR - TLR18RM & TLR18.

REAR VIEW

CTR - CTR WIDTH OF TOUGH BAR = CTR - CTR WIDTH OF TRACK:

REAR: 1035mm

FRONT: 1080mm

1. Fit Moulded Tracks to Roof Top Ditch as per Moulded Track Fitting Instructions.
 2. Measure the Centre to Centre width of the Tracks at the REAR and record the measurement.
 3. Measure the Centre to Centre width of the Tracks at the FRONT and record the measurement.
 4. With the TLR Roof Rack upside down, position Tough Bars on the specific Mounting Channels, as shown.
 5. Secure with M10 x 25 Hex. Set Screw, Star Washer, Flat Washer and Channel Nut.
 6. Move the Tough Bars evenly both sides of Centre line to the Centre's of the Roof Tracks as shown.
- NOTE: Tough Bars must be equal distance from both sides of Roof Rack - Front and Rear.**
7. Tighten fasteners firmly to secure Leg Bars to Roof Rack.
 8. With a person either side of the Roof Rack, carry the Roof Rack over the rear of the vehicle and lower it gently on the Roof Tracks.
- NOTE: Rear of Roof Rack to clear Shark Fin Aerial by approx. 15mm.**
9. Fit the Threaded Insert Plates into the Tracks (3 in each Track).
 10. Fit the M6x16 But. Soc. Screws with Star Washers and Flat Washer through Tough Bar Foot and thread into the Threaded Insert Plates in Track.
 11. Check clearance of Roof Rack from Aerial and tighten all Fasteners firmly.

NOTE: Check all Roof Rack and Tough Bar Fasteners regularly, especially after traveling over unsealed roads and rough terrain.

© JARAM AUSTRALIA 11-3-2020

UPDATED: 17-1-2022