

NOTICE DISPATCH STAFF - ASSEMBLY OF JARAM TOUGH BARS

- ALL SHARP EDGES MUST BE FINISHED BEFORE POWDER COATING.
- ADHESIVE 3mm FOAM TAPE MUST BE FITTED TO EACH ANGLE MOUNTING BRACKET BEFORE FITTING THE TOUGH BAR.
- **NOTE: THE FOAM TAPE MUST COVER THE BOTTOM OF THE ANGLE MOUNTING BRACKET AND WRAP AROUND THE BACK, BY 5mm.**
- FOOT PLATE MOUNTING HOLES MUST BE CUT OUT OF THE FOAM TAPE, FOR THE FASTENERS TO PASS THROUGH.
- M10 NYLOC FLANGE NUTS MUST BE USED TO SECURE TOUGH BARS TO ANGLE BRACKETS.

