

WIZZ NUT (M8)

FIT INSTRUCTIONS

TLRWN8 – TLR WIZZ NUT KIT



The **TRACKLANDER – WIZZ NUT (M8)** is designed to allow the easy fitment of all Tracklander Accessories to any Mesh Base Roof Racks where there is limited space between the Mesh and the Vehicle Roof top. Ideal for securing Gas Bottle Holders, Jerry Can Holders, Recovery Track Holders, etc. without having to get your hand under the Mesh Base.

The Tracklander Wizz Nut (TLRWN8) is a 160mm x 40mm Galvanised & Powder Coated Steel Plate with 2 x M8 Threaded Holes in the base. The tabs at both ends lock into the Mesh Base as the M8 Stainless Steel Fasteners tighten into one of the Threaded holes.

The TRACKLANDER WIZZ NUT mounted to a TRACKLANDER ROOF RACK.



- Position Accessory in desired position.
- Slide Wizz Nut down through hole in Mesh.



- Feed M8 Set Screw with Flat Washer and Star Washer through hole into Wizz Nut Threaded Hole.

NOTE: Apply a little Spray Lube (WD40 or CRC) to Stainless Steel threads before tightening, to prevent binding.



- Align one of the Wizz Nut Threaded holes with the Accessory mounting hole .



- Hold Wizz Nuts in position and tighten evenly, until firm.