

## **STRUT NUT- FASTENING METHOD**

1. PUSH SET SCREW WITH STRUT NUT, UP AND INTO CENTRE OF CHANNEL.
2. ROTATE STRUT NUT CLOCKWISE UNTIL SERRATED GROOVES LOCK INTO EDGES OF CHANNEL.
3. WHEN ALL STRUT NUTS ARE LOCKED INTO CROSS MEMBER CHANNELS, CHECK ROOF RACK IS CENTRALISED WITH TROUGH BARS, THEN TIGHTEN FIRMLY.

