


## TLRXLB160P


(Toughbar for Mitsubishi Triton )

Roof Rack(TLRAL14/FT)

Wind Deflector(TLRWD13X)



Thank you for purchasing a TRACKLANDER 4WD ROOF RACK. Before you start, take a moment to familiarise yourself with the Fitting Instructions and the components received. Refer to the next section for a list of all the components, quantities and tools required.



No	Item	Qty
*1	Roof Rack(TLRAL14FT)	1
2	Tough Bar X(Pair-XLB160)	1
3	X Bracket	4
*4	Wind Deflector(TLRWD13X-Kit, includes *14, *15, *16, *17 & #20) )	1

Note: Items marked with \* are sold separately

Fasteners Kit for Tough Bar

5	M10 x 25mm Hex Bolt, S/S	6
6	M10 Star Washer, S/S	6
7	3/8 x 1 <sup>1</sup> / <sub>4</sub> Flat Washer S/S	6
8	M10 Strut Nut	6

Fasteners for X Bracket


9	M10 x 25mm Button Cap Socket Head Screw	4
10	3/8 x 3/4 Flat Washer, SS	4
11	M6 x 16mm Hex Bolt, SS	4
12	M6 Star Washer	4
13	1/4 x 3/4 Flat Washer, SS	4

Fastener Kit for Wind Deflector

*13	M8 Star Washer, S/S	4
*14	M8 x 25mm Button Cap Socket Head Screw, S/S	4
*15	$\frac{5}{16}$ X 1 $\frac{1}{4}$ , Flat washer, S/S	4
*16	M8 Strut Nuts, Z/P	4
Foam Pad		
#17	Acoustic Foam Tape, (60x40x3mm) Affix to Toughbar, 2 per side	4
#18	Acoustic Foam Tape, (1100, FS126-9), Affix underneath the front cross member of the Toughbar	2

Note: \*14, '15, '16, \*17 & #20 are provide only for purchase of a complete kit

Tools required
5mm Hexagon Wrench/Key, M8
Size 10mm Spanner for M6 Hex Bolt
Size 17mm Spanner for M10 Hex Bolt
Measuring Tape

Recommended Torque Setting for fasteners	
M6	
M8	
M10	

## Step 1: Setting up of Tough Bar onto the roof rack

- Remove Covers to expose the mounting holes





- Push the cover forward with a plastic/wooden block.
- Once the cover disengage, remove to reveal the mounting holes.
- Repeat for all the 4 covers.

- Attach the X-brackets onto the mounting holes



Affix Acoustic Foam Pad




**Illustration above showing the pair of brackets on the right hand side of the vehicle.**

**Make sure the taper side of the bracket face each other.**

Attached the Tough Bar onto the Roof Rack as illustrated below:


- Lightly tighten the fasteners to allow for adjustment of the Tough Bar lateral spacing distance.

**\*Note: Setup distance is equal on opposite side**






Tough Bar Fastener Kit

60x30x3 Foam Pad




-Rest the tip of the measuring tape against the inner face of the rack edging  
 \*Position the measuring tape below the mounting hole location of the Tough Bar




- Tighten all the fasteners once the desirable distances are achieved.

## Step 2: Install the Wind Deflector (WD13X)


- Apply Acoustic Foam Tape on to the Roof Rack Frontal Area



- Secure the Wind-deflector onto the front of the rack as per the illustration shown below:




- Centralise and tighten.



\*Wind Deflector fitted to the front channel.

### Step3: Installation of Roof-rack assembly onto the vehicle

- With 2 people either side of the Roof Rack, carry the Roof Rack over the rear of the vehicle and rest the Tough Bar gently over the X-Brackets that you have installed on the vehicle's roof earlier.



- Secure the Roof Rack Assembly with the M10x25mm Button Cap Socket Screws and  $\frac{3}{8} \times \frac{3}{4}$  Flat Washers.
- Check to ensure that all fasteners are fully secured.
- The installation is now completed and ready to be used.



## SAFETY

- Cargo must be secured firmly onto the Roof Rack during operation at all times.
- Frequently check the tightness of cargo on the Roof Rack, especially when travelling over rough terrain or off-road
  - » Use only non-stretchable fastening ropes or straps to attach cargo onto the Roof Rack.
- Extreme care must be taken in off road conditions.

## MAINTENANCE

- All bolted connections should be checked after driving a short distance when you first install your roof racks
- All bolted connections should be checked at regular intervals, depending on road conditions, usage, loads and distances travelled
- All bolted connections should be checked each time they are re-fitted.



**IMPORTANT WARNING!**

IT IS CRITICAL THAT ALL TRACKLANDER 4WD ROOF RACK PRODUCTS BE PROPERLY AND SECURELY ASSEMBLED AND ATTACHED TO YOUR VEHICLE. IMPROPER ATTACHMENT COULD RESULT IN AN VEHICLE ACCIDENT, AND COULD CAUSE SERIOUS BODILY INJURY OR DEATH. YOU ARE RESPONSIBLE FOR ASSEMBLING AND SECURING ALL TRACKLANDER 4WD ROOF RACK PRODUCTS TO YOUR VEHICLE, CHECKING THE ATTACHMENTS PRIOR TO USE, AND PERIODICALLY INSPECTING THE PRODUCTS FOR ADJUSTMENT, WEAR AND TEAR. THEREFORE, YOU MUST READ AND UNDERSTAND ALL OF THE INSTRUCTIONS AND PRECAUTIONS SUPPLIED WITH YOUR TRACKLANDER 4WD ROOF RACK AND ACCESSORIES PRIOR TO INSTALLATION OR USE. IF YOU DO NOT UNDERSTAND ALL OF THE INSTRUCTIONS AND WARNINGS, OR IF YOU HAVE NO MECHANICAL EXPERIENCE AND ARE NOT THOROUGHLY FAMILIAR WITH THE INSTALLATION PROCEDURES, YOU SHOULD HAVE THE PRODUCT INSTALLED BY A PROFESSIONAL INSTALLER OR OTHER QUALIFIED PERSON.

NOTE: TRACKLANDER 4WD ROOF RACKS will not be responsible for any damage caused by the failure to install the product according to these instructions. Please call us if you have any questions about the installation of this product.

**TRACKLANDER 4WD ROOF RACKS**

T : (08) 9451 0700 E :[sales@tracklander.com.au](mailto:sales@tracklander.com.au) W :[tracklander.com.au](http://tracklander.com.au)  
A:12 Railway Parade, Welshpool, WA 6106  
OPEN 8.00AM - 5.00PM MON-FRI